


OBIS LASER SOLD SEPARATELY



EMISSION INDICATOR CAN BE MOUNTED TO EITHER SIDE OF OBIS LASER HEAD

