

Fibers Spinning Light

## **Optical Fibers for Gyroscope Coils**

Nufern offers a broad range of fibers for fiber optic gyroscopes including our latest high performance (HP) versions optimized for smallest diameter and exceptional splicability. We specialize in PANDA and Elliptical Clad designs and have a custom portfolio including SM and PM Gyroscope fibers. All products have very tight dimensional tolerances and use our proprietary coating critical for manufacturing highest precision, high-performance gyro-coils. Nufern Gyro fibers especially pure silica core SM versions have very high levels of radiation resistance suitable for myriad applications. Our Panda-style PM Gyro fibers have extremely high birefringence, negligible mode field perturbations and low cross-talk for maximum competitive advantage.





# Fibers Spinning Light Optical Fibers for Gyroscope Coils



## **Optimized Fiber Coating Technology**

Nufern has developed its own proprietary fiber coating optimized for gyroscope applications. This new proprietary NuCOAT-LTg coating offers improved crosstalk performance and is optimized for Nufern's world class fiber draw process.

#### **Optical Features & Benefits**

- Low bend loss Lowest power consumption and longest coil lengths
- Low mode field perturbation along length Minimizes crosstalk
- Hi birefringence Minimizes crosstalk
- Available in high performance (HP) versions optimized for improved repeatability, coil winding accuracy, and ultra-low splice loss

#### **Mechanical Features & Benefits**

- Very high fatigue failure resistance n<sub>d</sub> ~ 23 Ensures long life in tough conditions
- COST218 model based life expectancy of > 130 years with 25 mm bend radius and 5 km fiber
- Standard glass/polymer diameters as small as 40/90 µm For max fiber length on a small coil diameter

Product Number	Core Diameter	Cladding Diameter	Coating Diameter	Ø Coating Tolerance	NA	Beat Length @ 633 nm	Cross Talk for 100 nm	h-Parameter (X10 <sup>-5</sup> )	Special Features
Wavelength 1550 nm									
S1550-80	7.8 µm	80 µm	125 μm	± 5 μm	0.160	N/A	NA	N/A	SM Radiation Hard
S1550-80-HTA									
S1550-HTA		125 μm	245 μm	± 15 μm					
PM1550G-40/90-5	4.0 μm	40 μm	90 µm	± 5 μm	0.220	≤ 1.5 mm	≤ -20.0 dB	≤ 10.0 m <sup>-1</sup>	Small Clad & Coating
PM1550G-80/135-2HP	5.9 μm		135 µm	± 2 μm	0.190	≤ 1.2 mm	≤ -25.0 dB	≤ 3.0 m <sup>-1</sup>	High Performance, Thin Coating
PM1550G-80/170-5	5.5 µm	80 μm	170 um	± 5 μm	0.200				Standard
PM1550G-80/170-2HP	5.9 µm		170 μm	± 2 μm	0.190				High Performance
Wavelength 1300 nm									
PM1300G-80/135-2HP	5.2 μm	80 μm	135 µm	± 2 μm	0.180	≤ 1.2 mm	≤ -25.0 dB	≤ 3.0 m <sup>-1</sup>	High Performance, Thin Coating
PM1300G-80/170-5	5.0 μm 5.2 μm		170 μm	± 5 μm					Standard
PM1300G-80/170-2HP				± 2 μm					High Performance
PME1300G-80/170-5	6.0 µm			± 5 μm					Elliptical-Clad
Wavelength 850 nm									
PM850G-80/135-2HP	3.1 µm	3.1 μm 3.5 μm 3.1 μm	135 µm	± 2 μm	0.155	≤ 1.2 mm	≤ -25.0 dB	≤ 3.0 m <sup>-1</sup>	High Performance, Thin Coating
PM850G-80/170-5	3.5 µm		170 μm	± 5 μm	0.160				Standard
PM850G-80/170-2HP	3.1 µm			± 2 μm	0.155				High Performance
PME850G-40/100-5	3.5 µm	40 μm	100 µm	± 5 μm	0.180	≤ 2.0 mm @ 850nm	≤ -25.0 dB @ 633nm	≤ 5.0 m <sup>-1</sup>	Elliptical-Clad

