


## DIAMOND C-70 Series

# Low Power CO<sub>2</sub> OEM Lasers for Marking, Engraving, and Cutting Applications

The Coherent C-70  $CO_2$  laser provides 70 Watts of power with best-in-class reliability and package size, making it well suited for demanding high speed and large area laser marking and engraving systems, as well as many cutting applications. This production-ready, easy-to-integrate laser system enables high performance with low maintenance and operating costs. The C-70 is ideal for laser processing of many materials, including paper, plastics, wood, rubber, leather, cloth and more.

The C-70 is part of the Coherent C-series family of products which offer a full range of power levels – from 20 W to 70 W. Based on a sealed waveguide and integrated RF power supply design, the C-70 boasts outstanding production-proven reliability, while delivering excellent beam quality, power stability and pulse control in a compact, flexible and integrated package. The modular platform design provides cost-effective optimization of operating wavelength (from 9.3 to 10.6  $\mu$ m) and cooling configuration (air/liquid), enabling rapid adaptability to changing applications and market needs.



#### **FEATURES & BENEFITS**

- Superior beam quality, power stability and reliability
- Industry leading compact size with integrated RF power supply
- Versatile power range and pulse frequency control (CW or PWM)
   High speed laser processing on a wide range of materials
- Available in multiple wavelengths (9.3 µm to 10.6 µm) and cooling configurations (air or liquid)

#### **APPLICATIONS**

- Marking
- Engraving
- Cutting
- Medical and Dental
- Food, Beverage and Pharmaceutical Packaging
- Microelectronics and Consumer Flectronics
- Automotive and Electronic Components



SPECIFICATIONS <sup>1</sup>	Diamond C-70A (10.2 μm)	Diamond C-70A	Diamond C-70L (10.2 μm)	DIAMOND C-70L
Wavelength (μm)	10.11 to 10.31	10.55 to 10.63	10.11 to 10.31	10.55 to 10.63
Optical Output Power¹ (W)	70			
Power Stability <sup>2</sup> (%)	±5		±3	
Mode Quality (M <sup>2</sup> )	<1.3			
Beam Size (mm)	3.6 ±0.5 at output aperture			
Beam Divergence (mrad, full angle)	<5			
Polarization	>100 to 1 (fixed linear, parallel to width dimension)			
Operating Frequency and Duty Cycle	0 to 200 kHz, 0 to 100% DC			
CONFIGURATION AND FACILITY R	REQUIREMENTS			
Weight	10.2 kg (22.5 lbs.)		9.7 kg (21.5 lbs.)	
Dimensions (L x W x H)	604.9 x 92.5 x 154.5 mm (23.8 x 3.64 x 6.08 in.)		647.5 x 92.5 x 104.1 mm (25.5 x 3.64 x 4.1 in.)	
Input Power <sup>3</sup>	48 VDC, 20A			
Cooling	Air		Liquid	
Heat Dissipation (W)	<1200			
Maximum Case Temperature	<60°C (140°F)			
Operating Environment				
Temperature	5 to 40°C (41 to 113°F)			
Altitude	<2000 m (6500 ft.)			
Humidity	Non-condensing			
Shipping/Storage Environment	-10 to 60°C (14 to 140°F), non-condensing			
Coolant	Distilled water with 25 to 35% Dow Frost*			
Coolant Flow Rate	>3.8 lpm (1.0 gpm)			
Maximum Coolant Pressure	7 kg/cm² (100 psig)			
Max. Pressure Differential (at 1.0 gpm)	3.2 bar (46 psig) 15 to 30°C (59 to 86°F)			
Coolant Temperature	15 (0 30 °C (59 (0 80°F)			

- Power measured at 25°C and derated by 1%/C for higher laser head temperatures.


  Power stability based on ±(P<sub>max</sub> P<sub>min</sub>)/(2\*P<sub>max</sub>) average power measurement at constant duty cycle after 10-minute warm-up at operating condition.

  Optional fans add 1A.

  Dow Frost is a trademark of the Dow Chemical Company.




### **MECHANICAL SPECIFICATIONS**





#### **MECHANICAL SPECIFICATIONS**





Coherent, Inc., 5100 Patrick Henry Drive Santa Clara, CA 95054 p. (800) 527-3786 | (408) 764-4983

f. (408) 764-4646

tech.sales@coherent.com www.coherent.com

